



rail line
Field bus coupler RL DP



Interface description

PROFIBUS-DP

9499-040-77111

valid from: 11/2005



SIMATIC® is a registered trademark of Siemens AG

STEP® is a registered trademark of Siemens AG

is a registered trademark of the

PROFIBUS user organization (PNO)

BluePort® and BlueControl® are registered trademarks of

PMA Prozeß- und Maschinen-Automation GmbH

SyCon® is a registered trademark of

Hilscher Gesellschaft für Systemautomation GmbH

Legend of symbols:



General information



General warning



Caution: ESD-hazardous components

© 2004-2005 PMA Prozeß- und Maschinen-Automation GmbH • Printed in Germany
All rights reserved. No part of this document may be reproduced or published in any form
or by any means without prior written permission from the copyright owner.

A publication of PMA Prozeß- und Maschinen Automation
Postfach 310229
D-34058 Kassel
Germany

Content

1. General	5
1.1 References	5
1.2 GSD file	6
1.3 Additional information	6
2. Safety hints	7
2.1 Maintenance, modification and repair	8
2.2 Cleaning	8
2.3 Spare parts	8
3. Quick entry	9
4. Commissioning	10
4.1 Hints for installation	10
4.2 Dimensions	10
4.3 Mounting	11
4.3.1 Dismounting	11
4.4 Electrical connections	12
4.4.1 Bus coupler supply voltage	12
4.4.2 Energization via RL PWR power supply module	12
4.4.3 Bus structure	13
4.4.4 Connector	13
4.4.5 Cable layout	13
4.4.6 Screening	14
4.4.7 Terminating resistors	14
4.5 PROFIBUS settings	15
4.5.1 Bus address	15
4.5.2 Communication parameters	15
4.6 Displays	16
5. System design	17
5.1 System structure	17
5.1.1 Hints for connection	17
5.1.2 Operation without bus coupler	18
5.2 General system structure	19
5.2.1 Minimum equipment of a PROFIBUS system	19
5.2.2 Maximum equipment of a PROFIBUS system	19
5.2.3 Wiring inside buildings	20
6. Process data transmission	21
6.1 Selectable process data modules	22
6.2 Predefined objects (A.x modules)	22
6.2.1 Module A.1: Parameter channel	22
6.2.2 Module A.2: Data module : write order enabling	22
6.3 Freely selectable transfer object (analog modules)	23
6.3.1 Process data module "without data"	23
6.3.2 Process data modules in integer format	23
6.3.3 Process data modules in floating point format	24
6.3.4 Example: specification of the number of process data	24

7. User parameter setting	25
7.1 Parameter setting for DPV0 master	25
7.1.1 System-wide parameter setting	25
7.1.2 Function module parameter setting	25
7.1.3 Fail-safe	27
7.1.4 Example: module selection	28
7.2 Parameter setting for DPV1 master	29
8. PROFIBUS DP diagnosis information	30
8.1 Standard diagnosis message	30
8.2 Device-specific diagnosis	31
9. Engineering via PROFIBUS	32
9.1 BlueControl® via PROFIBUS-DPV1	32
9.1.1 CIF card settings	33
9.1.2 BlueControl® settings	33
9.2 Hints for DP master set-up	34
10. Quick entry	35
10.1 Example: SIMATIC® S7	35
10.2 Example: make Hilscher interface card	38
10.2.1 Versions for DPV0	38
10.2.2 Versions for DPV1	41
11. Address areas and -formats	42
11.1 Area definitions	42
11.2 Special values	42
11.3 Composition of the address tables	43
11.4 Internal data types	43
11.5 Annex of status / control information	44
11.5.1 Transmitter UNIFLEX CI 45	44
11.5.2 Universal controller KS 45	46
11.5.3 Temperature limiter TB 45	49
12. BlueControl engineering tool	50
12.1 Defining the configuration	50
12.2 Comparison with actual configuration	52
12.3 Viewing the process data on the bus coupler	52
12.4 Processing a function module engineering	53
12.4.1 Individual engineering	53
13. Index	54

1

General

Thank you very much for buying a *rail line* series device. This document describes the PROFIBUS interface functions of field bus coupler RL DP, which is called bus coupler in the following description, and the system capability of the various module versions of the *rail line* series (CI45-1xx-2..., KS45-1xx-2..., TB45-1xx-2....), called "function module" in the following description. The term "device" applies to both bus coupler and function modules.

Bus couplers with a PROFIBUS interface permit the transmission of process, parameter and configuration data. Field bus connection is via a sub-D socket at the top of the bus coupler. The serial communication interface facilitates connections to supervisory systems, visualization tools, etc.

Another standard interface is the non-bussable 'BluePort®' front-panel (PC) interface. It is used for direct connection of the 'BlueControl®' tool which runs on a PC.

Communication on the PROFIBUS-DP is according to the master/slave principle. The bus coupler is always slave.

The most important features of the bus connection with their physical and electrical properties are:

- **Network topology**
Linear bus, with bus termination at both ends.
- **Transfer medium**
screened, twisted 2-wire copper cable
- **Cable length (without repeater)**
Cable length dependent on transfer rate, max. 1200m
- **Transfer rates**
The following transfer rates are supported:
9,6 ... 12000 kBit/s
- **Physical interface**
RS 485 via sub-D connector; connections can be made on site
- **Addressing**
1 ... 99

1.1

References

Additional information on the PROFIBUS protocol:

- [1] **PROFIBUS specifications**
– <http://www.profibus.com>

Other documentations of *rail line* series s:

- [3] **Universal transmitter UNIFLEX CI 45**
– Data sheet CI 45 9498 737 48313
– Operating note CI 45 9499 040 71441
– Operating manual CI 45 9499 040 71711
- [4] **Universal controller KS 45**
– Data sheet KS 45 9498 737 48513
– Operating note KS 45 9499 040 71541
– Operating manual KS 45 9499 040 71811
- [5] **Temperature limiter TB 45**
– Data sheet TB 45 9498 737 48413
– Operating note TB 45 9499 040 71641
– Operating manual TB 45 9499 040 71911

1.2

GSD file



The GSD file is available as a standard file with English texts (PMA_093A.gsd). The current version can be downloaded from item Software on our homepage www.pma-online.de.

1.3

Additional information

Information on bus coupler and function module parameter addresses is given in documentation 9499-040-78111.

2**Safety hints**

This device was built and tested in compliance with VDE 0411-1 / EN 61010-1 and was shipped in safe condition. The device meets European guideline 89/336/EEC (EMC) and is provided with the CE-marking. The device was tested before delivery and has passed the tests stipulated in the test plan. To maintain this condition and to ensure safe operation, the user must follow the hints and warnings given in this operating manual and operate the device in compliance with the information provided in this manual.

**Warning**

The device is provided exclusively for use as a measuring and control unit in technical systems.

**Warning**

If the device is damaged to an extent that safe operation is not possible, it must not be taken into operation.

ELECTRICAL CONNECTIONS

The electrical connections must conform to local standards (e.g. VDE 0100). The input leads must be kept separate from signal and mains leads.

A circuit breaker or a power switch must be provided for the device and marked accordingly in the installation. The circuit breaker or power switch must be installed near the device and should be easily accessible for the operator.

COMMISSIONING

Before device switch-on, ensure that the rules given below were followed:

- Ensure that the supply voltage corresponds to the specification on the type label.
- All covers required for contact safety must be fitted.
- Before device switch-on, check, if other equipment and/or facilities connected in the same signal loop is / are not affected. If necessary, appropriate protective measures must be taken.
- The device may be operated only when mounted in its enclosure.
- The temperature limits specified for operation of the device must be met before and during operation.

**Warning**

During operation, the ventilation slots of the housing must not be covered.

**Warning**

The measurement inputs are designed for measurement of circuits which are not connected directly with the mains supply (CAT I). The measurement inputs are designed for transient voltage peaks up to 800V against PE.

SHUT-DOWN

For permanent shut-down, disconnect the instrument from all voltage sources and protect it against accidental operation.

Before instrument switch-off, check that other equipment and / or facilities connected in the same signal loop is / are not affected. If necessary, appropriate measures must be taken.

2.1

Maintenance, modification and repair

The devices need no particular maintenance.

No operable controls are mounted inside the device, i.e. the operator must not open it.

Modification, maintenance and repair may be carried out only by trained, authorized persons. For this purpose, the user is invited to contact the PMA service.



Warning

When opening the devices, or when removing covers and components, live parts or terminals can be exposed.



Caution

When opening the devices, electrostatically sensitive components can be exposed.



The PMA service address and contact information are as given below:

PMA Prozeß- und Maschinen-Automation GmbH
Miramstraße 87
D-34123 Kassel

Phone +49 (0)561 / 505-1257
Fax +49 (0)561 / 505-1357
e-mail: mailbox@pma-online.de

2.2

Cleaning



Housing and front panel of the device can be cleansed using a dry, lint-free cloth.

2.3

Spare parts

The following accessories are permitted as spare parts for the device:

Description	Order no.
Connector set with screw terminals	9407-998-07101
Connector set with spring clamp terminals	9407-998-07111
Bus connector for fitting in top-hat rail	9407-998-07121

3

Quick entry

For installing a *rail line* system, please, proceed as follows:

- ➔ Determine system concept and function modules.
- ➔ Determine the function module order behind the bus coupler.
- ➔ Mount a bus connector for each module on the top-hat rail and push them together.
- ➔ Set the PROFIBUS address on the bottom of the bus coupler.
- ➔ To mount the bus coupler, snap it onto the left bus connector.
- ➔ Mount the function modules analogously in the planned order.
- ➔ Connect the bus coupler to the supply voltage.
- ➔ Set a unique address for each function module, which should start with 1 for the module next to the bus coupler, followed by module no. 2, etc. Please, don't leave an address gap. Adjusting the addresses can be done via front-panel keyboard or BlueControl® engineering tool.
- ➔ Write the engineering for each individual function module. Determine which data should be read and / or written via the field bus (menu Bus data (read) / Bus data (write)). Note the order of selected data.
- ➔ Make the function module wiring.
- ➔ Configure the bus coupler with the order of fitted function modules. Please, specify the actually fitted device types exactly. This can be done via BlueControl® or via the master tool for the PROFIBUS master.
- ➔ During configuration in the master tool (via GSD file), the selected slot position determines the required allocated function module address.
- ➔ Load the bus configuration into the PROFIBUS master.
- ➔ Connect the PROFIBUS cable with the device; take care to include the required bus terminating resistors.
- ➔ Start the data exchange with the PROFIBUS master !

4

Commissioning

4.1

Hints for installation

- Measurement and data lines should be kept separate from control and power supply cables.
- Sensor measuring cables should be twisted and screened, with the screening connected to earth.
- External contactors, relays, motors, etc. must be fitted with RC snubber circuits to manufacturer specifications.
- The unit must not be installed near strong electric and magnetic fields.



Warning

The unit is not suitable for installation in explosion-hazarded areas.



Warning

Faulty connection can lead to the destruction of the instrument.



Warning

The device may be operated only in environments for which it is suitable due to its protection type.



Warning

The housing ventilation slots must not be covered.



Warning

In plants where transient voltage peaks are susceptible to occur, the devices must be equipped with additional protective filters or voltage limiters!



Caution!

The device contains electrostatically sensitive components.



Warning


Please, follow the instructions given in the safety hints.

4.2

Dimensions

The bus coupler dimensions are shown in the following drawing. For the function module data, see the relevant operating manuals.

Fig. 1: Dimension




4.3

Mounting

Connection between bus coupler and function modules is via bus connectors, which snap onto the top-hat rail. Several devices are mounted side by side with high packing density. The bus links between the devices are made directly via the bus connectors.

Fig. 2 Mounting steps



The instruments are provided for vertical mounting on 35 mm top-hat rails to EN 50022.

If possible, the place of installation should be exempt of vibration, aggressive fluids (e.g. acid, lye), liquids, dust or other suspended matters.

Instruments of the *rail line* family can be mounted directly side by side. For mounting and dismounting, the min. distance above and below the instrument from other equipment should be 8 cm.

For installation of the bus connection, proceed as follows:

- ❶ Snap on the bus connectors (delivered with the device) onto the top-hat rail
- ❷ For high-density mounting, push the bus connectors together.
- ❸ Clip the instruments onto the top-hat rail via the bus connectors
- the internal system bus connection is ready!



Please, mount the bus coupler in the leftmost position and fit the function modules right of the bus coupler in the required order.



***rail line* instruments do not contain parts for which maintenance is compulsory and need not be opened by the customer.**




Warning

A field bus coupler can energize max. 16 function modules. For connecting a higher number of modules RL PWR power supply modules must be used.

4.3.1

Dismounting

Dismounting is in the inverse order of the steps described above.



4.4


Electrical connections

4.4.1

Bus coupler supply voltage

A system comprising bus coupler and one or several function modules is energized centrally via the bus coupler. Central energization reduces the wiring expenditure considerably.

Fig. 3: Bus coupler energy supply conn. buscoupler



Warning
Energization at the function modules is not permissible.



A bus coupler can energize max. 16 function modules. For extension possibilities, see chapter 4.4.2.

4.4.2

Energization via RL PWR power supply module

Power supply module RL PWR is used for energization of function modules with system interface via the bus connector in the top-hat rail.

For connecting a higher number of function modules to the bus coupler than permissible for energization, additional power supply modules must be used.

Applications:

- Supplementary energization of additional function modules
- Repartition to different installation levels (e.g. two rows in a control cabinet)
- Construction of separate potential levels
- A power supply module can energize up to 16 function modules.

Fig. 4: Energy supply connection




Fig. 5: Ex: power supply module



Warning
Energ. at the function modules is not permitted.



Warning
High-density mounting with other partial systems is not permissible.



Cascade connection of power supply modules is not permissible (see above).

4.4.3


Bus structure

The bus is a two-wire RS 485 cable.

All bus sharing RS 485 units are connected in parallel to signals RxD/TxD-N (Data A) and RxD/TxD-P (Data B).

The bus cable characteristics are specified in IEC 61158. Cable type A is suitable for transfer rates up to 12 Mbit/s. A twisted and screened 2-wire cable must be used.

Fig. 6 Cabling possibilities



Hints:

- ❶ Mount terminating resistors across Data A and B at the cable end. For procedure, see chapter 4.4.7.
- ❷ For screening, see chapter 4.4.6.


4.4.4

Connector

Field bus connection is via a "standard" PROFIBUS-DP connector. The connector is a sub-D socket to IEC 61158. Connection must be done by the customer.

Fig. 7 Bus connecting plug

Anschluss / connection:

PROFIBUS-DP

4.4.5

Cable layout

For connecting the field instruments, suitable bus cables for the application must be used. The wiring must comply with the general hints and regulations (e.g. VDE 0100):

- Cable layout in buildings (inside and outside cabinets)
- Cable layout outside buildings
- Potential compensation
- Cable screening
- Measures against interference voltages
- Length of tap line

In particular, the following information must be taken into account:

- With RS 485 technology, max. 32 field units can be connected in a segment at a bus cable. Several segments can be coupled by means of repeaters.
- The bus topology should be a line of max. 1000m length per segment. Extension by means of repeaters is permissible.
- The bus cable connection must be a "daisy chain" between field instruments rather than star-shaped.
- If possible, tap lines should be avoided to prevent reflections causing communication trouble. With higher transfer rates, tap lines are not permissible.
- The general hints for low-interference signal and bus cable wiring are applicable (see operating note „EMC – General information“ (9407-047-09118)).
- To increase the transfer safety, pairwise twisted and screened bus cables can be used.

4.4.6

Screening

The type of screening connection is dependent mainly on the expected interference.

- For suppression of electric fields, one end of the screening must be connected to earth. Always realize this measure at first.
- However, suppression of interference due to an alternating magnetic field is possible only, when the both ends of the screening are connected to earth. With earth circuits, however, note the screening effect is reduced by galvanic interference on the reference potential.
- If several devices are linked to a single bus, the screen must be connected at each device, e.g. by means of screen clamps.
- Short distance bus screening must have a large-surface, low-resistance connection to a central protective earth, e.g. via screening terminals

4.4.7

Terminating resistors

The PROFIBUS terminating resistors must be fitted at the end of each bus cable, construction acc. to IEC 61158. We recommend using commercially available PROFIBUS connectors with integrated terminating resistors.

4.5

PROFIBUS settings

4.5.1


Bus address

The address of a bus coupler for bus communication must be adjusted via two rotary selector switches at the bottom of the unit:

Range:

- 01 ... 99

Fig. 8 Address setting (below)



Each instrument in a PROFIBUS system must have a unique address.



Warning

When defining the device address, note that allocation of the same address to two instruments is not permissible, because it is susceptible of causing faulty behaviour of the overall bus. In this case, the bus master communication with the connected instruments is not possible.

4.5.2

Communication parameters

Transfer rate / cable length

The Baudrate is a measure for the transfer rate. The permissible cable length is dependent on this rate. The bus coupler supports the following transfer rates:

Transfer rate	Max. cable length
9,6 / 19,2 / 45,45 / 93,75 kBit/s	1200 m
187,5 kBit/s	1000 m
500 kBit/s	400 m
1,5 MBit/s	200 m
3 / 6 / 12 MBit/s	100 m

The transfer rate is selected automatically by the bus master.



The transfer rate setting of all bus sharing units must be equal.


Process data length

The max. length of a process data message can be 244 bytes (read and write).

4.6

Displays

Five bus coupler indicator LEDs indicate various operating statuses.



	Signification
1	System bus status indicator LED off: off blinks: searching modules on: communication active
2	Diagnostic indicator LED on: module error, alarm
3	Device status indicator LED * green: ok yellow: initialization yellow blinking: configuration difference red: no configuration red blinking: module failure
4	no function
5	Field bus status indicator LED off: no communication blinks: Wait / Param / Config / CPU Stop on: data exchange
6	Field bus telegram error LED off: no error blinks: parameter error on: configuration error
7	PC connection for engineering tool

* " green- yellow- red-
off" alternating display: internal error status

5

System design

Up to 16 function modules can be connected and energized at a bus coupler. System extension is possible by using power supply modules:

- Up to 62 function modules can be addressed logically by a bus coupler.
- Up to 4 installation levels can be built up.
- The max. permissible extension is 10 m.


5.1

System structure

Using power supply modules offers many advantages:

- The number of function modules connectable to a bus coupler can be extended.
- The function modules can be distributed to different levels in the control cabinet.
- A potential-isolated energy supply is possible.

Fig. 9: System structure possibility



The overall system length including cables must not exceed 10 m. Max. 3 m cable length between two groups is permissible.


5.1.1

Hints for connection

For connecting the function modules energized by the bus coupler and the function modules energized by the power supply module, proceed as follows:

- 1 Insert a connector (e.g. 9407-998-07141) on the right side of the group with the bus coupler into the bus connector in the top-hat rail.
- 2 Insert a connector (e.g. 9407-998-07131) on the left side of the group with the power supply module into the bus connector.
- 3 Use twisted and screened two-wire bus cable.
Connect conductor 1 with the lower contact S5 and conductor 2 with contact S4.
- 4 Terminate the system bus with a terminating resistor $LT = 100$.
For this, insert a connector (e.g. 9407-998-07141) on the right side of the last group with a power supply module into the bus connector. Connect the resistor across terminals S4 - S5.

Fig. 10: Connecting



Warning

Don't interconnect a bus coupler and one or several power supply modules via bus connector. Connections via contacts S1 to S3 can lead to damage of the connected devices!

5.1.2

Operation without bus coupler



Power supply module RL PWR can be used also for energization of function modules with system interface, if the use of a bus coupler is planned only for the future, or if only a single function module version may be available due to reduced stock-keeping.

5.2

General system structure



Please, follow the guidelines and instructions for building up a communication system given by the master manufacturer.

5.2.1

Minimum equipment of a PROFIBUS system

A PROFIBUS system comprises the following minimum equipment:

- a bus master, which controls the data communication,
- one or several slaves, which provide data on request by the master,
- the transfer medium, consisting of bus cable and bus connector for connecting the individual bus sharing units, one or several bus segments which are connected by repeaters.

5.2.2

Maximum equipment of a PROFIBUS system

A bus segment comprises max. 32 (active and passive) field instruments. The maximum possible number of slaves which can be operated at a PROFIBUS master over several segments is determined by the internal master memory structure. Therefore you should get information on the master capacity when planning a system.


The bus cable can be opened at any point to include another unit by adding a bus connector. At the segment end, the bus cable can be extended up to the predefined segments lengths. The length of a bus segment is dependent on the adjusted transfer rate, which is determined mainly by system constellation (segment length, distributed inputs/outputs) and required scanning cycles *Abfragezyklen* of individual units. The selected transfer rate must be equal for all bus units.



PROFIBUS units must be connected in line structure.

A PROFIBUS system can be extended by using repeaters for connection of more than 32 units, or for longer distances than defined according to transfer rate.

Fig. 11 Structure



A fully equipped PROFIBUS system can include max. 125 units with addresses 1 ... 125. Each repeater reduces the maximum number of units in a segment. As a passive unit, a repeater does not have a PROFIBUS device address. However, its input circuitry is an additional load for the segment due to bus driver current consumption. But a repeater is without effect on the overall number of units connected on the bus. The maximum number of repeaters which can be connected in series may vary dependent on manufacturer. For this reason, you should get information on possible limitations from the manufacturer when projecting a system.

5.2.3

Wiring inside buildings

The following hints for cable layout are applicable to twisted-pair cables with screen. The screening improves the electromagnetic compatibility.

Depending on requirements, the one or both ends of the cable screen must be connected to a central earth point (PE) by means of low-impedance connections with a large surface, e.g. screen clamps. When installing a repeater or field unit in a control cabinet, the cable screen should be connected to an earth rail mounted as close as possible to the cable entry into the cabinet.

The screening must be continued up to the field instrument and connected with the conductant housing and/or metal connector. Ensure that the earth potential of the instrument housing and of the control cabinet accommodating the field instrument is equal due to large-surface metal contact. Mounting a screening rail on a painted surface is without effect.

By observing these measures, high-frequency interference will be grounded reliably via the cable screens. Should external interference voltages still reach the data lines, the voltage potential will be raised symmetrically on both lines, so that in general, no destructive voltage differences can arise. Normally, a shift of the ground potential by several volts will not have an effect on reliable data transmission. If higher voltages are to be expected, a potential balancing conductor with a minimum cross-section of 10 mm^2 should be installed parallel to the bus cable, with connections to the reference ground of every field unit. In case of extreme interference, the bus cable can be installed in a metal conduit or channel. The conduit tube or the channel must be earthed at regular distances.


The min. distance between bus cable and other leads carrying more than 60 V must be 20 cm. The bus cable must be kept also separate from telephone cables and cables leading into hazardous areas. In these cases, we recommend installing the bus cable in a separate cable duct.

When installing a cable duct, only conductant materials connected regularly with the reference potential should be used. Mechanical stress and obvious damage must of the bus cables must be avoided. Unless this is possible, special protective measures, e.g. installation in a pipe, etc. are required. such aslf thisDie Buskabel sind keiner mechanischen Beanspruchung oder offensichtli

Floating installation

If the installation must be floating (no earth connection) for certain reasons, the device reference ground must only have a high-impedance connection to earth (e.g. an RC combination). The system will then find its own earth potential. When connecting repeaters for the purpose of linking two bus segments, a floating installation is recommended, to prevent possible potential differences being transferred from one segment to the next.

Fig. 12 Screening conn.



6 Process data transmission

For flexible realization of the requirements on transfer values, memory capacity and transfer rate, the user can compose the process data transmission from a predefined selection of process data modules. This configuration is by means of the relevant bus master configuration tool.

- ❶ In addition to the cyclically transmitted process data, parameter transmission on request via PROFIBUS-DP is also possible (see also chapter 1.3).

Fig.: 13 Hardware configuration example for SIMATIC® S7

Slot	Module / ...	Order number	I Address	Q Address	Comment
0	2AX	Analog I/O - 1 float IN/OUT	200...203	200...203	
1	1AE	Analog In - 1 word IN	256...257		
2	209	Analog In - 1 float IN	258...261		
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					

Process data and selected parameter data are written and read cyclically.

- ❶ Transmitted values are taken over by the function module only in case of value change.

Data format

Values such as process values and setpoints can be transmitted in floating point format or in 16-bit FixPoint format with one digit behind the decimal point (selectable).

- ❶ With FixPoint transmission, the following marginal conditions should be taken into account: For data defined as floating point values in the device, the following rules are applicable:
 - The values are multiplied by factor 10.
Example: 30.0 °C becomes 300.
 - The transferable range is within -3000.0 and +3200.0; transmitted values beyond this range are not accepted.
 - With read data out-of-range, value -3276.8 is transmitted (as an integer value -32768).
 - The transmitted switch-off value is 32000 with FixPoint format and -32000.0 with floating point format.

- ❶ For data which are defined as integer values in the device, conversion is omitted.

Parameter channel

Process, parameter and configuration data are accessible additionally via the parameter channel. These data are transmitted over several cycles on request.

6.1 Selectable process data modules

The cyclically transmitted process data are determined by the user during bus configuration. Predefined modules with defined content / data signification (A modules) and freely defined modules as space-keepers are available. The contents are determined via the device engineering.

6.2 Predefined objects (A.x modules)

A.x modules "Data module" and "Parameter channel" are objects with pre-defined contents.



A.x modules may be called up only once during bus parameter setting.

6.2.1 Module A.1: Parameter channel

This process data module for DPV0 operation can be used for acyclical access to the *rail line* system parameters.

Parameter channel		Module ID: F3hex / 243dec	
Read	Byte	Write	Byte
Response data	8	Request data	8

For a detailed description, see documentation 9499-040-78118.

- During DPV1 operation, this access is not necessary.
- The parameter channel should be used, when the relevant bus master can execute only a DPV0 data communication and more than 15 data have to be read or written by a function module.

6.2.2 Module A.2: Data module : write order enabling

This module is used to enable process value write operations. When using this module

- the PROFIBUS does not take over write data with value 0;
- the write values transmitted via the PROFIBUS are taken over with value 1;
- with change from 0 to 1 all write values are written into the device again by the PROFIBUS.

Process data		Module ID: 20hex / 32dec	
Read	Byte	Write	Byte
	0		1

- Unless module A.2 is used, the device will always store valid write data.

6.3

Freely selectable transfer object (analog modules)


A *rail line* function module is defined with each entry of a process data module into the hardware configuration. The number of data to be transmitted cyclically on the PROFIBUS is determined by selecting the process data module.

The content of transmitted data is selected in the engineering of the individual function module by means of the 'BlueControl[®]' engineering tool. Per module, max. 15 parameters and signals for read and write are available. The order of transmission is determined by the position.

The process data modules can be selected up to the limit determined by memory space or number of permitted modules.

- max. input length of process data: 244 bytes
- max. output length of process data: 244 bytes
- max. number of modules: 62
- max. number of transmissible data (read, write per function module): 15 (integer)

 Max. 16 function modules can be connected physically to a bus coupler. If energized by power supply modules, 62 function modules per bus coupler are addressable.

 Definitions:
Input data: read data seen from the bus master
Output data: write data seen from the bus master.

6.3.1

Process data module "without data"

The entry of process data module "module without data" is used, unless cyclical data should be transmitted during process data exchange, although a function module is defined. Parameter setting for this entry is also necessary (s. below).

6.3.2

Process data modules in integer format

The number of data transmitted on the PROFIBUS is determined by means of the process data modules. The data content is determined in the function module engineering.

For the integer / FixPoint format, the following modules are available:

IO type	Words	Variable	Format	Module ID	Data per module
I	1	IN1	FixP	50hex / 80dec	1 input
I	2	IN1 ... IN2	FixP	51hex / 81dec	2 inputs
I	4	IN1 ... IN4	FixP	53hex / 83dec	4 inputs
O	1	OUT1	FixP	60hex / 96dec	1 output
O	2	OUT1 ... OUT2	FixP	61hex / 97dec	2 outputs
O	4	OUT1 ... OUT4	FixP	63hex / 99dec	4 outputs
I/O	1/1	IN1 / OUT1	FixP	70hex / 112 dec	1 input / 1 output
I/O	2/2	IN1...IN2 / OUT1...OUT2	FixP	71hex / 113dec	2 inputs / 2 outputs
I/O	3/3	IN1...IN3 / OUT1...OUT3	FixP	72hex / 114dec	3 inputs / 3 outputs
I/O	6/6	IN1...IN6 / OUT1...OUT6	FixP	75hex / 117dec	6 inputs / 6 outputs
I/O	9/9	IN1...IN9 / OUT1...OUT9	FixP	78hex / 120dec	9 inputs / 9 outputs
I/O	12/12	IN1...IN12 / OUT1...OUT12	FixP	7Bhex / 123dec	12 inputs / 12 outputs
I/O	15/15	IN1...IN15 / OUT1...OUT15	FixP	7Ehex / 126dec	15 inputs / 15 outputs

6.3.3 Process data modules in floating point format

The number of data transmitted on the PROFIBUS is determined by means of the process data modules. The data content is determined in the function module engineering.

For floating point format, the following modules are available:

IO type	Words	Variable	Format	Module ID	Data per module
I	2	IN1	Float	D1hex / 209dec	1 input
I	4	IN1 ... IN2	Float	D3hex / 211dec	2 inputs
I	8	IN1 ... IN4	Float	D7hex / 215dec	4 inputs
O	2	OUT1	Float	E1hex / 225dec	1 output
O	4	OUT1 ... OUT2	Float	E3hex / 227dec	2 outputs
O	8	OUT1 ... OUT4	Float	E7hex / 231dec	4 outputs
I/O	2/2	IN1 / OUT1	Float	F1hex / 241dec	1 input / 1 output
I/O	6/6	IN1...IN3 / OUT1...OUT3	Float	F5hex / 244dec	3 inputs / 3 outputs
I/O	12/12	IN1...IN6 / OUT1...OUT6	Float	FBhex / 251dec	6 inputs / 6 outputs
I/O	16/16	IN1...IN8 / OUT1...OUT8	Float	FFhex / 255dec	8 inputs / 8 outputs



Please, note that these data have to be transmitted always as consistent data !

6.3.4 Example: specification of the number of process data

A rail line system comprises three function modules, each of which includes a different number of values to be transmitted:

- Module 1: an integer value (the first value is transmitted).
- Module 2: read an integer value, write an integer value (with each operation, the first value is transmitted).
- Module 3: read three float values, write three float values (with each operation, the first three values are transmitted).

Fig. 14: Selecting the number of values- on S7example

The screenshot shows the HW Config software interface. At the top, there's a title bar 'HW Konfig - [SIMATIC 300(1) (Konfiguration) -- RL_elfemo]'. Below it, a rack configuration is shown with three modules: 1. TAE, 2. SAX, and 3. Analog I/O. A table below the rack lists the modules with their addresses and comments. On the right, a list of available process data modules is shown, with 'Analog I/O - 3 float IN/OUT' selected. Three arrows on the left point to the first three rows of the table, labeled 'Module 1', 'Module 2', and 'Module 3'.

Steckplatz	Baugruppe / DP-Kennung	Bestellnummer	E-Adresse	A-Adresse	Kommentar
0	TAE	Analog In - 1 word IN	258, 257		
1	SAX	Analog I/O - 1 word IN/OUT	258, 259	258, 257	
2	SAX	Analog I/O - 3 float IN/OUT	269, 271	258, 269	
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					



The order of selected process data modules determines the function module assignment. Process data module 1 defines the number of data of the function module with address 1, process data module 2 determines the number of data for the function module with address 2, etc.

7

User parameter setting

7.1

Parameter setting for DPV0 master



After selection of the process data modules, the bus coupler and function module PROFIBUS user parameters must be adjusted.

In addition to the standard parameter data, the bus coupler has also user-specific parameter data which must be set via the bus configuration tool of the relevant bus master.

Distinction of the settings which are valid for the overall *rail line* system and settings for each function module is required.

7.1.1

System-wide parameter setting

The system-wide user parameter setting is valid for the function modules of a bus node. The significations of adjustable user parameter data (4th byte) are given in the following tables. These settings are not stored in the device, i.e. the default settings are activated after switch-on.

	Bit	Descr.	Signification	
1...3rd byte			Reserved for DPV1. These bytes are not used for DPV0 operation.	
	Bit	Descr.	Signification	Default
4th byte	0	Motorola / Intel format	Format for floating point values and integer values: Motorola (IEEE 754) / Intel (0 / 1) For connection also to non-compatible PLCs or PC cards. Example: The Motorola format of value 123.4 is: 42 F6 CC CD in Intel format, the value is CD CC F6 42	0 (Motorola)
	1	Diagnosis format (→ chapter 8.2 p.31)	Extended / standard diagnosis (0 / 1) Extended diagnosis: standard diagnosis plus device-specific diagnosis. Standard diagnosis: (6 bytes) without device-specific information.	0 (extended)
	2	Start up (presently not realized)	Data exchange start-up, if module configuration and inserted modules do not correspond Start: always start-up, data exchange with corresponding modules Don't start: no start-up with divergences	0 (start)
	3..7	reserved		0

7.1.2

Function module parameter setting

The user parameter setting comprises 3 bytes for each function module. It defines

- the corresponding instrument type and option for each function module and
- the behaviour in case of bus failure.



Device type and option must correspond with the actually inserted function modules, otherwise, error signalling will occur and no process data can be exchanged.



When starting up the PROFIBUS, the user parameter data are received in the bus coupler and stored as defined configuration. Earlier configurations are overwritten.



Configurations are pre-defined by the bus master when starting up the bus and need not be specified via BlueControl®.

The significations of user parameter data (byte 1 + 2) are given in the following tables:


	Descr.	Signification	Option version
1st...2nd byte	Device-ID	<p>"don't care"</p> <p>UNIFLEX CI 45</p> <p>„CI45-1x3-200x0-xxx Std“ „CI45-1x3-210x0-xxx Std+opt1“ „CI45-1x3-220x0-xxx Std+opt2“ „CI45-1x5-200x0-xxx 2rel“ „CI45-1x5-210x0-xxx 2rel+opt1“ „CI45-1x5-220x0-xxx 2rel+opt2“</p>	<p>Undefined module ❶</p> <p>1 relay 1 relay, option 1 1 relay, option 2 2 relays 2 relays, option 1 2 relays, option 2</p>
		<p>KS 45</p> <p>„KS45-1x1-200x0-xxx Std, di_ct“ „KS45-1x1-210x0-xxx Std, di_op“ „KS45-1x1-220x0-xxx 2AI, di_ct“ „KS45-1x1-230x0-xxx 2AI, di_op“ „KS45-1x3-200x0-xxx Std+AO, di_ct“ „KS45-1x3-210x0-xxx Std+AO, di_op“ „KS45-1x3-220x0-xxx 2AI+AO, di_ct“ „KS45-1x3-230x0-xxx 2AI+AO, di_op“ „KS45-1x5-200x0-xxx 2DO+rel, di_ct“ „KS45-1x5-210x0-xxx 2DO+rel, di_op“</p>	<p>2 relays, contact input 2 relays, opto-coupler input 2 relays, 2 universal inputs, contact input 2 relays, 2 universal inputs, opto-coupler input 2 relays, analog output, contact input 2 relays, analog output, opto-coupler output 2 relays, 2 universal inputs, analog output, contact input 2 relays, 2 universal inputs, analog output, opto-coupler input 2 opto-coupler outputs, 1 relay, 1 HC contact input 2 opto-coupler outputs, 1 relay, 1 HC opto-coupler input</p>
		<p>TB 45</p> <p>„TB45-1x1-200x0-xxx Std, di_ct“ „TB45-1x1-210x0-xxx Std, di_op“ „TB45-1x1-220x0-xxx opt1, di_ct“ „TB45-1x1-230x0-xxx opt1, di_op“ „TB45-1x3-200x0-xxx AO, di_ct“ „TB45-1x3-210x0-xxx AO, di_op“ „TB45-1x3-220x0-xxx AO+opt1, di_ct“ „TB45-1x3-230x0-xxx AO+opt1, di_op“</p>	<p>2 relays, contact input 2 relays, optocoupler input 2 relays, 2 universal inputs, contact input 2 relays, 2 universal inputs, opto-coupler input 2 relays, analog output, contact input 2 relays, analog output, opto-coupler output 2 relays, 2 universal inputs, analog output, contact input 2 relays, 2 universal inputs, analog output, opto-coupler input</p>

	Descr.	Signification	Default
3rd byte	Fail-safe	Module behaviour with bus errors; application dependent on system concept. last value (0): hold existing values zero (1): set values to 0 fault value (2): presently no function, behaviour as zero	0 (last value) 2

* Notes:

- ❶ Entry "don't care" can be used, unless the exact instrument description is known.
Caution: In the event of replacement, any other modules can be inserted.
- ❷ For definitions, see chapter 7.1.3.

Fig. 15: User parameter setting for Buscoupler - Example S7



7.1.3 Fail-safe

The fail-safe user parameter setting determines the device behaviour in case of bus failure or master 'bus stop'. In case of bus failure, the device operates according the following rules:

Fail-safe setting	Reaction in case of bus failure or master stop
<i>last value</i> (default)	continue with the values sent last forced analog inputs are set to FAIL
<i>zero</i>	forced analog inputs are set to FAIL forced digital inputs are set to zero forced outputs are set to zero remaining transmitted values remain unchanged
last value	presently no function (behaviour as zero)

- ❶ Fail-safe condition is detected also when a faulty PROFIBUS configuration telegram or a faulty user parameter byte no. 4 was sent.


7.1.4 Example: module selection

The configuration for the bus coupler is determined via the user parameter setting .

Example:

- CI 45, 24V (only these are permissible with system interface), 1 universal input, 1 analog output and 2 relays
Order no. CI45-115-2000-000

Fig. 16: Selecting the modules



The defined configuration of the function modules comprises the device type and the relevant version and options. It comprises also the allocated position / address.



Any configuration pre-defined via BlueControl® is overwritten when starting up the PROFIBUS.

7.2

Parameter setting for DPV1 master

In addition to the device-specific DPV0 parameter setting, further settings for DPV1 functions are possible. These settings are made also via the relevant bus master bus configuration tool.

With RL DP, the following functions can be selected and enabled:

- Operating mode according to DPV0 or DPV1

The user parameter setting is valid throughout the device. The following tables explain the significations of DPV1-specific settings (byte 1 to 3). The device-specific parameters (byte 4) are described in chapter 7.1, p.25. These settings are not stored in the device, i.e. the default settings are activated after switch-on.

DPV1 status 1

	Bit	Descr.	Signification	Default
1st byte	0..1	reserved		
	2	WD_Base_1ms	Device supports watchdog time base 1ms	1 (fixed)
	3..5	reserved		
	6	fail-safe	Device supports fail safe mode. In clear mode, the device accepts data telegrams without data.	1 (fixed)
	7	DPV1 enable	The class 1 master determines if the device should work in DPV0 or DPV1 mode. RL DP supports the two versions.	determ. by master

DPV1 status 2

	Bit	Descr.	Description	Default
2nd byte	0	Check_Cfg_Mode	RL DP checks configuration data as defined in IEC 61158	0
	1	reserved		
	2	Enable_Update_Alarm	Not supported	0
	3	Enable_Status_Alarm	Not supported	0
	4	Enable_Manufacture_Specific_Alarm	Not supported	0
	5	Enable_Diagnostic_Alarm	Not supported	0
	6	Enable_Process_Alarm	Not supported	0
	7	Enable_Pull_Plug_Alarm	Not supported	0

DPV1 status 3

	Bit	Descr.	Signification	Default
3rd byte	0..2	Alarm_Mode	Not supported	0
	3..7	reserved		

8 PROFIBUS DP diagnosis information

PROFIBUS DP offers a convenient and complex possibility to process diagnosis messages due to error conditions. The RL DP diagnosis information comprises standard diagnosis information (6 bytes) and additional device-specific diagnosis information. The latter can be switched off via the user parameters.

8.1 Standard diagnosis message

A standard diagnosis message comprises 6 bytes.

	Bit	Descr.	Signification
1st byte	0	Diag.station	Does not exist (sets master)
	1	Diag.station_not_ready	Slave is not ready for data exchange
	2	Diag.cfg_Fault	Configuration data do not correspond
	3	Diag.ext_diag	Slave has external diagnosis data (Only used with diagnosis setting "extended")
	4	Diag.not_supported	Requested function is not supported in slave
	5	Diag.invalid_slave_response	Fixes slave to 0
	6	Diag.prm_fault	Faulty parameter setting (ident number etc.)
	7	Diag.master_lock (sets Master)	Slave is programmed by other master

Standard diagnosis

	Bit	Descr.	Signification
2nd byte	0	Diag.Prm_req	Slave parameters must be set again The application has detected a condition which requires restart with a corresponding new parameter setting and configuration. In response to this diagnosis, the master realizes a start-up with predetermined parameter setting and configuration.
	1	Diag.Stat_diag	Static diagnosis (byte diagnosis bits) Due to the status in the application, the slave cannot make valid data available. As a consequence, the master requests only diagnosis information, until the slave resets this bit. However, the PROFIBUS DP status is data exchange, i.e. data exchange can be continued immediately after reset of the static diagnosis (presently not used).
	2	Fixed to 1	
	3	Diag.WD_on	Response monitoring active
	4	Diag.freeze_mode	Freeze command received
	5	Sync_Mode	Sync command received
	6	reserved	
	7	Diag.deactivated	(Set by the master)

	Bit	Descr.	Signification
3rd byte	0..6	reserved	
	7	Diag.ext_overflow	This bit is set by the slave, when the number of diagnosis data exceeds the capacity of the available diagnosis data memory area.

	Bit	Descr.	Signification
4th byte	0..7	Diag.master_add	Master address after parameter setting (0xFF without parameter setting)

	Bit	Descr.	Signification
5th byte	0..7		Ident number (high byte); 0x09

	Bit	Descr.	Signification
6th byte	0..7		Ident number (low byte); 0xAC

8.2

Device-specific diagnosis

The following device-specific diagnosis (during DPV1 mode: status messages) can be switched off via user parameter setting (→section 7 p.25). This permits switching over to the standard diagnosis, e.g. for earlier DP masters which do not support all the functions, or when displayed diagnosis information is not of interest.

Structure from byte 7:

- Length information (1 byte)
- Bus coupler: software version (1 byte)
- Bus coupler: reserve (2 bytes)
- Per function module: alarm and status information (7 bits) / (max. 55 bytes)

Device-spec. diagnosis

	Bit	Descr.	Signification
7th byte	0..5	Header byte	Length in bytes incl. header byte'
	6, 7		Always '0' '0'
	Bit	Descr.	Signification
8th byte	0..7	Software version	Bus coupler software version, e.g. V1.2 = 0Chex
	Bit	Descr.	Signification
9th byte	0..7	Reserve	Bus coupler: reserve
	Bit	Descr.	Signification
10th byte	0..7	Reserve	Bus coupler reserve
	Bit	Descr.	Signification
11th byte	0	Module 1 - alarm type 1	Bit 0: alarm type 1 (e.g. sensor break, short circuit ...)
	1	Module 1 - alarm type 2	Bit 1: alarm type 2 (e.g. stored alarm, heating current alarm ...)
	2	Module 1 - status type 1	Bit 2: status type 1 - device error or information (E.1 ... E.4, Inf.1, Inf.2)
	3	Module 1 - wrong output value	Bit 3: transmitted values out of defined limits (e.g. setpoint out of setpoint range)
	4	Module 1 - communication error	Bit 4: communication error (e.g. communication with module failed, device missing ...)
	5	Module 1 - device configuration mismatch	Bit 5: Defined configuration unequal to actual configuration
	6	Module 1 - reserved	
	7	Module 2 - alarm type 1	Bit 0: alarm type 1 (e.g. sensor break, short circuit ...)
	Bit	Descr.	Signification
12th byte	0	Module 2 - alarm type 2	Bit 1: alarm type 2 (e.g. stored alarm, heating current alarm ...)
	1	Module 2 - status type 1	Bit 2: status type 1 - device error or information (E.1 ... E.4, Inf.1, Inf.2)
	2	Module 2 - wrong output value	Bit 3: transmitted values out of defined limits (e.g. setpoint out of setpoint range)
	3	Module 2 - communication error	Bit 4: communication error (e.g. communication with module failed, device missing ...)
	4	Module 2 - device configuration mismatch	Bit 5: defined configuration unequal to actual configuration
	5	Module 2 - reserved	
	6	Module 3 - alarm type 1	
	7	Module 3 - alarm type 2	

...

 Please, note that the diagnosis values are not displayed correctly by earlier Simatic® S7 masters.

9 Engineering via PROFIBUS

The field bus coupler can be used to download a complete engineering from BlueControl®, or to read it from the field bus coupler into the PC. This feature permits construction of central engineering stations without passing the data e.g. through a PLC. RL DP supports up to two acyclical connections to class 2 masters and one connection to the class 1 master.

To set up an acyclical connection process as described below:

- Determine the target rotation time
- Set up BlueControl® transmission.

9.1

BlueControl® via PROFIBUS-DPV1

Data transmission between BlueControl® and the field bus coupler is easy using the DPV1 functions. Both a complete engineering and operating functions as well as trend recording can be transmitted or realized.

- ① Engineering tool BlueControl® from version 1.5 supports PROFIBUS PC cards make Hilscher, e.g. CIF50-PB, CIF60-PB, firmware version $\geq 1.0.71$.
- ① Engineering tool BlueControl® from version 2.4 supports additionally PROFIBUS PC cards make Siemens, e.g. CP5613.

How to make the settings required at the engineering tool and for the PROFIBUS card is explained below at the example of a PC card maker Hilscher.

9.1.1 CIF card settings

Case 1:

The instrument is not integrated into a PROFIBUS network.
The CIF card must be initialized with master address and Baudrate (see Fig 17 as an example).

Case 2:

The instrument is integrated into a network with other DP masters, e.g. S7.

A free master address must be allocated to the CIF card. Adjust the Baudrate already used at the master.



The target rotation time must be matched and adjusted on all masters connected on the PROFIBUS (see below).

Only the CIF card needs to be defined as C2 master (no device required as slave).

Case 3:

The device is integrated into an engineering with the selected CIF card as a slave.

Access to the device is as a C1 communication. For description, see chapter 10.2, p.38 .

Subsequently, the bus coupler must be connected with the CIF card.

9.1.2 BlueControl® settings

- Choose field "PC connection" to select the communication channel to BlueControl® with PROFIBUS 1 to 4 (max. 4 PROFIBUS cards can be fitted in the PC.)
- Specify the address (PROFIBUS address) to define the device to be selected.



For transmission from BlueControl®, we recommend the following settings when using make Hilscher interface cards:

Device: set "Motorola = 0" as user parameter Motorola/Intel format.

DP master: set "low/high byte" as memory format Byte"



Unless communication with the Hilscher interface card can be built up, the causes can be e.g.:

- The device contains an earlier software version (error message -7)
- The device is defined as a DPV0 slave and access to the device by the engineering tool is via a class 1 master (error message 1132).
- The max. channel data length in the device DPV1 settings is too low (error message 1132). The device is designed for 240 bytes.
- There is no communication to the device (error message 1129).
- The target rotation time is too small by design (error message 1129).



Warning

Only one engineering tool per device at a time may be in data exchange.

Fig. 17: C2 - Configuration of the master





Fig. 18: Selecting the communication channel



9.2

Hints for DP master set-up

For smooth operation, the following settings of the DP master are required:

- Enable the DPV1 functionality at the master and for the selected device.
- If necessary, define the "max. channel data length " (240 bytes).
- Check or set the target rotation time.



The target rotation time (Ttr) must not be adjusted to a too low value, otherwise, the acyclical message cannot be handled. This time defines the maximum available time for a token cycle during which all active DP masters get the sending right once.



When using one or several class 1 master(s) and one or several class 2 master(s) in a multi-master system, the target rotation time must be set to the same value with all masters, e.g. the total of all single times.



With low PROFIBUS transfer rates (9,6 or 19,2 kBit/s), the preset target rotation time must be increased by at least factor 4.



Warning

A faulty target rotation time can lead to communication trouble.



The DPV1 transfer times are dependent on Baudrate, total number of transmitted data and length of transferred data in the addressed instrument. Example: typical values for transmission of an instrument engineering are within 15 sec. and 3 min.

Further information on the acyclical data transmission is given in interface description "SB PROFIBUS-DP rail line parameter data" (9499-040-78118).

10

Quick entry

10.1

Example: SIMATIC® S7

The examples in this chapter show how to build up a DPV0 communication with a *rail line* PROFIBUS system and a SIMATIC S7 easily.

Test environment

For the test set-up, the following components are required:

- Programming unit or PC with PC adaptor
- Programming tool STEP®7 ≥ V5.0
- Automation unit
 - e.g. CPU S7 315-2 DP, recent version

Components

- e.g. RL DP, (e.g. order number. RL40-112-00000-000)
- one or several devices from the *rail line* series
 - e.g. universal controller KS 45 (e.g. order no. KS45-113-20000-000)
 - e.g. transmitter UNIFLEX CI 45 (e.g. order no. CI45-113-20000-000)
 - e.g. temperature limiter TB 45 (e.g. order no. TB-113-20000-000)
- Cable
 - PROFIBUS cable automation unit ↔ RL DP with PROFIBUS connectors and integrated terminating resistors
 - programming unit ↔ automation unit

Example of a test environment:

Task

- Connection of an RL DP with address 5 to a CPU CPU315-2 DP via PROFIBUS-DP
- Process value display of the connected function modules
- The process values should be transmitted as integer value (1 value).



Before taking the test environment into operation, ensure the the automation unit does not contain a different user software ("initial delete")


Procedure;

Procedure

- Snap the bus connector onto the top-hat rail.
- Configure the RL DP bus coupler.
 - Set address 5 and snap the device onto the top-hat rail.
 - Connect the supply voltage.
- Configure the required function modules.
 - Click the device in position on the top-hat rail.
 - Address the modules (starting from #1, via front-panel key or BlueControl®).
 - Load the engineering into the device.
 - Select "Bus data (read)" as process value in Signals\Device\C.Inp via BlueControl® in parameter setting mode.
- Make the connections (PROFIBUS)
 - Activate the bus terminating resistors.
- PROFIBUS network configuration


- Define device in Step®7 - HW - Config

Fig. 21: Step7: Selecting the modules




- User parameter setting
 - Realize system-wide parameter setting.

Fig. 19: User parameter setting for Buscoupler - Example S7



- Set the function module parameters.

Fig. 20: Selecting function modules



- Transmit the hardware configuration to the DP master.
- Switch the automation unit to Run.

- Set up a variable table in monitor mode and display the measured values.

Fig. 22: Displayed in the monitor

	Address	Display format	Status value	Modify value
1	PEW 256	DEC	406	
2	PEW 258	DEC	343	
3	PEW 260	DEC	251.5	
4				

10.2

Example: make Hilscher interface card

10.2.1

Versions for DPV0

The examples in this chapter show how to build up a DPV0 communication with a *rail line* PROFIBUS system and a make Hilscher interface card easily.

Test environment

For the test set-up, the following components are required:

- PC / notebook
- SyCon® system configurator
- a CIF® interface card
 - e.g. CIF50-PB, CIF60-PB

Components

- e.g. RL DP, (e.g. order no. RL40-112-00000-000)
- one or several devices of the *rail line* series
 - - e.g. universal controller KS 45 (e.g. order no. KS45-113-20000-000)
 - - e.g. transmitter UNIFLEX CI 45 (e.g. order no. CI45-113-20000-000)
 - - e.g. temperature limiter TB 45 (e.g. order no. TB-113-20000-000)
- Cable
 - PROFIBUS cable between automation unit ↔ RL DP with PROFIBUS connectors and integrated terminating resistors programming unit ↔ automation unit

Test environment example:

Task

- An RL DP with address 5 should be connected to a CIF60-PB via PROFIBUS-DP.
- The process values of the connected function modules should be displayed.
- The process values should be transmitted as integer value (1 value).



Before taking the test environment into operation, ensure that the automation unit does not contain a different user software. Abschnitt muss weg

Procedure:

- Snap the bus connector onto the top-hat rail.
- Configure the RL DP bus coupler.
 - Set address 5 and snap it onto the top-hat rail.
 - Connect the supply voltage.
- Configure the required function modules
 - Click the devices in position on the top-hat rail
 - Address the modules (starting from #1, via front-panel keys or BlueControl®)
 - Select “Bus data (read)” as process value in Signals\Device\C.Inp via BlueControl® in parameter setting mode.
 - Load the engineering into the device.


Procedure

- Make the connection (PROFIBUS)
 - Activate the bus terminating resistors.
- PROFIBUS network configuration
 - If necessary adapt addresses and bus master hardware configuration and transmit them to the DP master (menu Online\Download).
 - Start the communication.

Procedure and typical settings for this example are shown in the following figures:

- Network structure

Fig. 23: Example network structure for SyCon



- Selection of process data modules

Fig. 24: Selection of process data modules

General
 Device: RL DP rail line Station address: 1
 Description: Slave5
 Activate device in actual configuration
 Enable watchdog control GSD file: PMA_093A.GSD

Max. length of in-/output data: 488 Byte Length of in-/output data: 31 Byte
 Max. length of input data: 244 Byte Length of input data: 20 Byte
 Max. length of output data: 244 Byte Length of output data: 11 Byte
 Max. number of modules: 65 Number of modules: 5

Module	Inputs	Outputs	In/Out	Identifier
A. 1: General-Parameter			4 Word	0xF3
A. 2: Data module		1 Byte		0x20
A. 3: Status module	8 Byte			0x17
Module without data				0x00
Analog In - 1 word IN	1 Word			0x50
Analog In - 2 word IN	2 Word			0x51

Slot	Idx	Module	Symbol	Type	I Addr.	I Len.	Type	O Addr.	O Len.
0	1	A. 1: General-Parameter	Module1	IW	0	4	QW	0	4
1	1	A. 2: Data module	Module2				QB	8	1
2	1	A. 3: Status module	Module3	IB	8	8			
3	1	Analog	Module4	IW	0	2			
4	1	Analog	Module5				QW	0	1

- System-wide DPV0 user parameter setting

Fig. 25: DPV0 user parameter setting

Slave Configuration
 General
 Device: RL DP rail line Station address: 1
 Description: Slave5


Parameter Data
 Description: Common Parameter Data

Byte	Description	Value
3	Motorola/Intel format	IEEE(Motorola)
3	Diagnosis format	extended
3	Start-up	Start

Diagnosis format dialog:
 extended (selected)
 standard


- Function module parameter setting

Fig. 26: Parameter setting function modules



- Master settings


Fig. 27: Master settings SyCon



i For consistent data transmission, “buffered” transmission procedure must be selected. The memory format must be set to “Little Endian” (Motorola).

- Data can be displayed in the network view.

Fig. 28: Network view



10.2.2 Versions for DPV1

RL DP can be defined as DPV1 slave. Possible settings are given on the following picture.

Fig. 29: DPV1 - parameter settings

Additional Slave Functions

Cyclic connection

No Abort if slave not responding
 Abort if slave is not responding

Auto Clear

Process the Autoclear function
 Ignore the Autoclear function

Fail Safe Support

0 Data is sent in CLEAR mode
 No Data is sent in CLEAR mode

DPV1 activated

Maximum Channel Data Length Maximum Alarm PDU Length

Diagnostic Update Delay Maximum active Alarms

Slave Functions

Extra Alarm Service Access Point

Master Alarmacknowledge SAP51
 Master Alarmacknowledge SAP50

Configuration Data convention

Configuration Data of EN 50170
 Configuration Data of DPV1

Enabled Alarms

Pull Plug Alarm Manufacturer Alarm
 Process Alarm Status Alarm
 Diagnostic Alarm Update Alarm

OK
Cancel
OPC Symbols

11**Address areas and -formats****11.1****Area definitions**

The address is coded in 2 bytes. The most significant 3 bits determine the data transmission format. The following formats are available for *rail line* devices:

- **Integer**
- **Integer with 1 decimal**
- **(Float acc. to IEEE)**

Address area		Data transfer format	Smallest transferable value	Largest transferable value	Resolution
hex	dez.				
0x0000 ... 0x1FFF	0 ... 8191	Integer without decimals	-30000	+32000	+/- 1
0x2000 ... 0x3FFF	8192 ... 16383	Integer with 1 decimal	-3000.0	+3200.0	+/- 0.1
0x4000 ... 0x7FFF	16384...32767	Float (IEEE format)	-1.0 E+037	+1.0 E+037	+/-1.4E-045



For integer numbers with and without decimals, the value range -30000 to +32000 is transmitted via the interface. Scaling with the factor 1 or 10 must be carried out by the transmitting device as well as by the receiving device.

11.2**Special values**

The following special values are defined for transmission in the **integer format**:

- 31000 Sensor fault
This value is returned for data that do not represent a meaningful value due to a sensor fault.
- 32000 Switch-off value
The function is disabled.
- 32500 Undefined value
The device returns this value, if a datum is not defined within the requested range („NOT DEFINED VALUE“).
- 32768 Corresponds to 0x8000 hex.
The value to be transmitted lies outside the transferable integer value range.

The following special values are defined for transmission in the **Float format**:

- 1.5E37 This datum is not defined.
The device returns this value, if a datum is not defined within the requested range.

11.3**Composition of the address tables**

In the address tables shown in Section 5, the addresses for every parameter of the corresponding data format are specified in decimal values.

The tables are structured as follows:

Name	R/W	Address	Integer	Real	Type	Value/off	Description
		base 1dP					

- Name Description of the datum
- r/w permitted type of access: R = read, W = write
- Address integer Address for integer values
- base Integer without decimals
- 1 dP Integer with 1 decimal
- Real Floating point number / Float (IEEE format)
- Type internal data type
- Value/off permissible value range, switch-off value available
- Description Explanations

11.4**Internal data types**

The following data types are assigned to data used in the device:

- Float
Floating point number
Value range: -1999 ... -0.001, 0, 0.001 ... 9999
- INT
Positive whole integer number
Value range: 0 ... 65535
Exception: Switch-off value '-32000'
- Text
Text string consisting of n characters, currently defined n = 5
Permissible characters: 20H...7FH
- Long
Positive whole Long number
Value range: 0 ... 99999
- Enum
Selection value

11.5**Annex of status / control information**

The signification of selectable status and control information for the transmitted bus data (read / write) are explained in this chapter.

11.5.1**Transmitter UNIFLEX CI 45****Status words**

Name	r/w	Type	Value/off	Description
St.Di	r	Int	...	Status of digital inputs or of keys (in binary code).
			Bit 0: input di1, Bit 8: status of Enter key Bit 9: status of decrement key, Bit 10: status of increment key	
St.Ain	r	Int	0...127	Analog input status in bit code (error, e.g. short circuit)
			Bit 0 break at input 1 Bit 1 wrong polarity at input 1 Bit 2 short circuit at input 1 Bit 3 not used Bit 4 break at input 2 Bit 5 wrong polarity at input 2 Bit 6 short circuit at input 2 Bit 7-15 not used	
St.Ala	r	Int	...	Alarm status: the status of individual alarms such as exceeded limit value in bitwise code
			Bit 0 pending/stored exceeded limit value 1 Bit 1 pending/stored exceeded limit value 2 Bit 2 pending/stored exceeded limit value 3 Bit 3-7 not used Bit 8 pending exceeded limit value 1 Bit 9 pending exceeded limit value 2 Bit 10 pending exceeded limit value 3 Bit 11-15 not used	
St.Do	r	Int	0...15	Digital output status
			Bit 0 digital output 1 Bit 1 digital output 2 Bit 2 digital output 3	
Fail	r	Enum	<i>Enum_InpFail</i>	Error at input, faulty or incorrectly connected sensor
			0 no error 1 sensor break 2 faulty input polarity 4 short circuit at input	

Control words

Name	r/w	Type	Value/off	Description
F.Di	r/w	Int	0...1	Digital input forcing. Forcing means external control of a device input, the device stores the value on this input (defined for device inputs by the supervisory system, e.g. for function testing).
			Bit 0	Forcing for digital input 1
F.Do	r/w	Int	0...15	Digital output forcing. Forcing means external control of at least one output, the device does not influence this output (use of free device outputs by the supervisory system)
			Bit 0	digital output 1 forcing
			Bit 1	digital output 2 forcing
			Bit 2	digital output 3 forcing

11.5.2

Universal controller KS 45

Status words

Name	r/w	Type	Value/off	Description
St.Di	r	Int	...	Status of digital inputs or of keys (in binary code).
			Bit 0: input di1 Bit 8: Enter key status Bit 9: Decrement key status Bit 10: Increment key status	
St.Ain	r	Int	0...127	Status of analog inputs (error, e.g. short circuit in bit code)
			Bit 0 break at input 1 Bit 1 wrong polarity at input 1 Bit 2 short circuit at input 1 Bit 3 not used Bit 4 break at input 2 Bit 5 wrong polarity at input 2 Bit 6 short circuit at input 2 Bit 7-15 not used	
St.Ala		Int	...	Status of alarms: the status of individual alarms such as exceeded limit value and loop in bitwise code
			Bit 0 pending or stored exceeded limit value 1 Bit 1 pending/stored exceeded limit value 2 Bit 2 pending/stored exceeded limit value 3 Bit 3 not used Bit 4 pending/stored loop alarm Bit 5 pending/stored heating current alarm Bit 6 pending/stored SSR alarm Bit 7 not used Bit 8 pending exceeded limit value 1 Bit 9 pending exceeded limit value 2 Bit 10 pending exceeded limit value 3 Bit 11 not used Bit 12 pending loop alarm Bit 13 pending heating current alarm Bit 14 pending SSR alarm Bit 15 not used	
St.Do	r	Int	0...15	Digital output status
			Bit 0 digital output 1 Bit 1 digital output 2 Bit 2 digital output 3	
Fail	r	Enum	<i>Enum_InpFail</i>	Error at input, faulty or incorrectly connected sensor
			0 no error error 1 sensor break 2 faulty polarity at input 4 short circuit at input	

Ada.St	Enum	Enum_AdaStart	starting / stopping the adaptation After the start signal, the controller waits, until the process has reached the process at rest condition (PIR) and starts self-tuning. Self-tuning can be cancelled manually at any time. After successful self-tuning, the controller resets the signal automatically .
		0	Stopping the adaptation leads to cancelation of the adaptation, the controller changes to control operation with the parameter values valid before adaptation start.
		1	Adaptation start is from manual or from control operation.

St.Tune	r	Int	0...65535	Self-tuning status information, e.g. the actual condition and any results, warnings and error messages
		Bit 0	process at rest; 0 no; 1 yes	
		Bit 1	controller self-tuning mode; 0 off; 1 on	
		Bit 2	controller self-tuning result; 0 OK; 1 error	
		Bit 3 - 7	not used	
		Bit 8 - 11	result of heating attempt	
		0 0 0 0	no message /attempt running	
		0 0 0 1	successful	
		0 0 1 0	successful with exceeded set-point hazard	
		0 0 1 1	error: faulty output action	
		0 1 0 0	error: no process reaction	
		0 1 0 1	error: low return point	
		0 1 1 0	error: exceeded limit limit value hazard	
		0 1 1 1	error: output step change too small	
		1 0 0 0	error: set-point reserve too small	
		Bit 12 - 15	result of cooling attempt (as heating attempt)	

St.Prog	r	Int	0...255	The programmer status contains e.g. at which point of the program sequence the program is in bit code .
		Bit 0,1,2	segment type 0: rising, 1: falling 2: holding	
		Bit 3	program run	
		Bit 4	program end	
		Bit 5	program reset	
		Bit 6	program start flank missing	
		Bit 7	program BandHold + FailHold	
		Bit 8	programmer active	

Control words

Name	r/w	Type	Value/off	Description
F.Di	r/w	Int	0...1	Digital input forcing. Forcing means external control of a device input, the device stores the value on this input (defined for device inputs by supervisory system e.g. for function testing.)
				Bit 0 forcing for digital input 1
F.Do	r/w	Int	0...15	Forcing of digital outputs. Forcing means external control of at least one output, the device does not influence this output (use of free device outputs by supervisory system)
				Bit 0 digital output 1 forcing
				Bit 1 digital output 2 forcing
				Bit 2 digital output 3 forcing

11.5.3 Temperature limiter TB 45

Status words

Name	r/w	Type	Value/off	Description
St.Di	r	Int	...	Status of digital inputs or of keys (in binary code).
			Bit 0: input di1 Bit 8: Enter key status Bit 9: Decrement key status Bit 10: Increment key status	
St.Ain	r	Int	0...127	Status of analog inputs (error, e.g. short circuit) in bit code)
			Bit 0 break at input 1 Bit 1 wrong polarity at input 1 Bit 2 short circuit at input 1 Bit 3 not used Bit 4 break at input 2 Bit 5 wrong polarity at input 2 Bit 6 short circuit at input 2 Bit 7-15 not used	
St.Ala	r	Int	...	Status of alarms: the status of individual alarms such as exceeded limit value in bitwise code
			Bit 0 pending/stored exceeded limit value 1 Bit 1 pending/stored exceeded limit value 2 Bit 2 pending/stored limit value 3 Bit 3-7 not used Bit 8 pending exceeded limit value 1 Bit 9 pending exceeded limit value 2 Bit 10 pending exceeded limit value 3 Bit 11-15 not used	
St.Do	r	Int	0...15	digital output status
			Bit 0 digital output 1 Bit 1 digital output 2 Bit 2 digital output 3	
Fail	r	Enum	<i>Enum_InpFail</i>	error at input, faulty or incorrectly connected sensor
			0 no error 1 sensor break 2 faulty input polarity 4 input short circuit	

12 BlueControl® engineering tool

This chapter describes how to handle the BlueControl® system assistant for rail line instruments.



Only the expert system assistant version is available.



The procedure described below is not necessary with the PROFIBUS-DP bus coupler RL DP, because the settings are made via the bus master parameter setting tool.

12.1 Defining the configuration

Before taking a field bus node into operation, the configuration must be defined. Enter order, function module type and device version.

The coupler module selected in **Device selection** is always set into position "0" automatically. This is the head station of the *rail line* system. All communication via the field bus is via this module. The following modules are called function modules.

❶ Select the function module type by means of double click on the module or by clicking on the function module and on button "Add entry" (1) in window "System configuration".

❷ Define the exact device configuration

❸ Only versions with 24V and system interface are permissible.

❸ Determine the order. The order can be changed by one position at a time using "Move entry up" (3) or "down" (4). Click on button "Remove entry" (2) to remove an entry.

Allocated buttons:

❸ See also on-line help of the tools,



which can be called up via button "Help".

- ❹ On page "Parameter", the module settings for the behaviour in the system are adjustable.
- The data type describes the format of process data transmitted via the bus (integer / floating point). The process data are determined when setting the parameters of the individual modules.
 - The group parameter determines which values are output by the modules in case of bus transmission failure between external master (PLC) and bus coupler. (see chapter xxxx)

Fig. 30: System configuration view of the function modules





Fig. 31: Configuration of device behaviour




- 5 Assign addresses 1 to n (via front panel keys or engineering tool) to the function modules in mounting order starting at the coupler).
- 6 The defined configuration is sent to the bus coupler via the front-panel interface, and stored.



Unless the defined configuration corresponds to the actually provided function modules, an error is output.

Fig. 32: Error display



Error message explanation:

Error	Description	Causes
OK	Everything ok	
Coupler (01)	Communication error	<ul style="list-style-type: none"> Module not fitted Module failed Error on system bus
Coupler (02)	Deviation from defined configuration	<ul style="list-style-type: none"> Defined configuration does not correspond to the fitted module.
Module (01)	A sensor alarm was output	<ul style="list-style-type: none"> Sensor break detected Short circuit or wrong polarity detected
Module (02)	A limit value was exceeded	<ul style="list-style-type: none"> Limit value exceeded Heating current alarm generated
Module (04)	Device-specific information	<ul style="list-style-type: none"> Device error occurred Maintenance manager signal (operating hours, number of switching cycles)
Module(08)	Write value out of limits	<ul style="list-style-type: none"> Setpoint out of adjusted limits Value out of permissible limits

The error code digits are in HEX format.



Error messages can be generated also in combination.

Examples:

- Module (03) = exceeded limit value + sensor alarm
- Coupler (03) = communication error + configuration divergence;
cause e.g. faulty module address
- Module (0E) = exceeded write value + device error + limit value exceeded.



Reset of error messages can be displayed also only after a second read operation.

12.2

Comparison with actual configuration

When loading the engineering from the field bus coupler, the defined configuration is read. Unless error “coupler (xx)” is displayed, the defined configuration corresponds to the actual configuration.

12.3

Viewing the process data on the bus coupler

On on-line connection to the bus coupler is built up via button “Connection to device” .
The following information per configured function module is provided:

- 1 Function module type with position number
- 2 Error status (see below)
- 3 Read process data, values read by the module (defined in the module engineering)
- 4 Written process data, data written by the bus coupler (defined in the module engineering)

Fig. 33: Overview of process data

Description	Value
CI 45 rail line [1]	
Status	0000 0000
Read 1	30.01
Write 1	
TB 45 rail line [2]	
Status	0000 0000
Read 1	257
Write 1	
KS 45 rail line [3]	
Status	0000 0000
Read 1	2515
Read 2	-1000
Write 1	

Status information structure:

D7	D6	D5	D4	D3	D2	D1	D0
----	----	----	----	----	----	----	----

Bit no.	Signification (with Dx = 1)	Cause	corresponds to error
D0	Sensor alarm generated	<ul style="list-style-type: none"> • Sensor break detected • Short circuit or wrong polarity detected 	Module (01)
D1	Limit value exceeded	<ul style="list-style-type: none"> • Limit value exceeded • Heating current alarm generated 	Module (02)
D2	Device-specific information	<ul style="list-style-type: none"> • Device error detected • Maintenance manager signal (operating hours, number of switching cycles) 	Module (04)
D3	Write value out of limits	<ul style="list-style-type: none"> • Setpoint out of the adjusted limits • Value out of the permissible limits 	Module (08)
D4	Communication error	<ul style="list-style-type: none"> • Module not fitted • Module failed • Error on system bus 	Coupler (01)
D5	Divergence from defined configuration	<ul style="list-style-type: none"> • Defined configuration does not correspond to actually inserted module. 	Coupler (02)
D6-D7	Reserved		



Write values can be defined during on-line mode, unless a field bus interface is connected.

12.4

Processing a function module engineering

12.4.1

Individual engineering


A device engineering can be transmitted into the function module in different modes:

- connection via the module front-panel interface
- connection via the bus coupler front-panel interface and further transmission via internal system bus

In the second case, the module is addressed as follows:


- 1 Click on the selected module in the system assistant.
- 2 Click on button "Parameter and configuration" or select menu "View - Parameter".
- 3 Load the device engineering from the module, process it and restore it in the device.

Fig. 34: Functionmodule-engineering



- i** When transmitting the information, "Front" must be defined in item "Device connection". The module index is entered automatically.

Fig. 35: Selecting the communication channel



13 Index

A	
Address areas	42 - 49
Address formats	42 - 49
Addressing	5
Area definitions	42
B	
BlueControl® via PROFIBUS-DPV1	32 - 33
Bus address	15
Bus connectors	11
Bus protocol	21 - 24
C	
Cable screen	20
Cleaning	8
Commissioning	10 - 16
Composition of the address tables	43
D	
Data format	21
- FixPoint	21
Defining the configuration	50 - 51
E	
Electrical connections	12 - 14
Engineering via PROFIBUS	32 - 34
F	
Fail-safe	27
- Last value	27
- Zero	27
Format	
- Float	42
- Float acc. to ieee	42
- Integer	42
Freely selectable objects	23 - 24
H	
Hints for DP master set-up	34
Hints for installation	10
I	
Internal data types	43
M	
Maintenance	8
Maximum equipment	19
Modbus addresses	42 - 49
Modules	
- A.1	22
- A.2	22
- B	23
- C	24
Mounting	11
N	
Network topology	5
P	
Parameter channel	21 - 22
Power plug	12
Predefined objects	22
Process data length	15
Q	
Quick entry	35 - 41
S	
Safety hints	7 - 8
Screening	14
Spare parts	8
Special values	42
- Sensor fault	42
- Undefined value	42
Supply voltage	
- Bus coupler	12
- Power supply module	12
T	
Transfer rate	5, 15
Transmission format	42
U	
User parameter setting	25 - 29
- DPV0-Master	25 - 28
- DPV1-Master	29
W	
Wiring	20



9499-040-77111

Subject to alterations without notice
Änderungen vorbehalten
Sous réserve de toutes modifications

© PMA Prozeß- und Maschinen-Automation GmbH
P.O.B. 310 229, D-34058 Kassel, Germany
Printed in Germany 9499-040-77111 (11/2005)

A4, unibind, SW-Druck, Normalpapier 80g weiß